

## POWERCOIL

### Powercoil Wood Shaft Models and Specs:

SHAFT	FLEX	LENGTH	WEIGHT	TORQUE	TIP OD	BUTT OD	PARALLEL TIP	BEND POINT
Powercoil RH50	Stiff	46"	51gr	4.2	.335"	.600"	3.5"	Mid
Powercoil RH50	Regular	46"	51gr	4.6	.335"	.600"	3.5"	Mid
Powercoil RH50	Flexible	47"	51gr	5.2	.335"	.580"	6.5"	Low
Powercoil RH50 (.350")	Stiff	46"	54gr	4.2	.350"	.600"	4.0"	Mid
Powercoil RH50 (.350")	Regular	46"	54gr	4.6	.350"	.600"	4.0"	Mid
Powercoil RH50 (.350")	Senior	46"	54gr	4.9	.350"	.585"	4.0"	Mid
Powercoil RH65	X-Stiff	48"	73gr	3.0	.335"	.615"	3.5"	Mid
Powercoil RH65	Stiff	46"	66gr	3.1	.335"	.600"	3.5"	Mid
Powercoil RH65	Regular	46"	63gr	3.5	.335"	.600"	4.5"	Mid
Powercoil RH65	Senior	46"	63gr	3.5	.335"	.600"	4.5"	Mid

### Powercoil Tip Trimming Instructions:

SHAFT	DRIVER	3W*	5W*	7W*	9W*
Powercoil HP50	Butt trim only	1.0"	1.5"	2.0"	2.5"
Powercoil HP65	Butt trim only	1.0"	1.5"	2.0"	2.5"

\*Tip trim can be adjusted to fine tune playing characteristics.

\*Tip trim should not exceed (Parallel Tip - Hosel Depth).

\*Perform tip trim and then butt trim to final playing length.